



# USER MANUAL

## Contents

### 1 Basic Knowledge

#### 1.1 Synopsis

#### 1.2 Safe

#### 1.3 Safe Warning and Attention Matter

### 2 Before Use

#### 2.1 Every part's name and instruction

#### 2.2 Battery

#### 2.3 Network connection

### 3. Basic operations

- 3.1 Make a call
- 3.2 Emergency call
- 3.3 Answer a call
- 3.4 Call history
- 3.5 Call menu
- 4. Function menu
  - 4.1 Phonebook
  - 4.2 Messages
  - 4.3 MMS
  - 4.4 Voice Box
  - 4.5 Call record
  - 4.6 Calendar
  - 4.7 Games
  - 4.8 Service
  - 4.9 Milt-Media
  - 4.10 Additional features
  - 4.11 Setting
  - 4.12 Profiles
  - 4.13 Shortcut Function
  - 4.14 File Manager
  - 4.15 Phone TV
  - 4.16. FM Radio

4.17 Audio player

4.18 film player

4.19 Film Recorder

4.20 Camera

5. Input Methods

## 1. Basic Knowledge

### 1.1 Synopsis

Thank you for choosing color screen series mobile phone. Reading this use handbook, you can know the phone thoroughly; understand its perfect function and simple operation.

This color mobile phone designed according to GSM/GPRS network environment. Except normal call function, it contains mobile phone TV, Bluetooth, Frequency modulation broadcast, Chinese/handwrite input, name card phonebook, 64 and ring, Clock and Alarm, Schedule manager, Unit converter, Health, Calculator, Games, Mp3 player, Camera, Film recorder, Video recorder and so on, which good for your job and activity. Moreover, this color mobile phone use individual man-phone screen, its perfect function design can satisfy your different require.

This phone conforms to the GSM/GPRS technology standard, and award home and abroad authoritative organization authentication.

### 1.2 Safe

- If your phone lost or stole, please inform telecommunication department or sales point immediately, to stop using the phone and SIM card. This will help you avoid others use your phone to bring your economic lost.
- When you contact with telecommunication department, they need to know your mobile phone's IMEI no.(print on the label of phone back, can find it after take off the battery). Please write down this number and save it, in case future use.
- To avoid your phone misuse, please adapt guard measure, such as:
  - Setting phone SIM card's PIN number, revise it before others know it.
  - While leaving your car, please don't put your phone in easy to see place, better take it or lock it.
  - Setting call limit.

### 1.3 Safe Warning and Attention Matter

#### General Attention Matter

- Your phone can only use our company's battery and charger. Using other product may cause battery leak, too hot, rupture and on fire.

- No strong hit, vibration or throw the phone, in case the phone has accident or on fire.
- Please don't put the battery, phone, charger on the microwave oven and high pressure unit, otherwise it may cause electric circuit damage and fire accident.
- Don't use your phone in flammable explosive place; otherwise it may cause phone breakdown and fire.
- Please don't put your phone on high temperature, high humid and massive dust place, otherwise it will cause breakdown.
- Please put the phone out of children's reach, in case the children take it as toy, and cause person injury.
- Please don't put the phone on not smooth and not steady place, in case drop it.

### **Attention Matter of Using Mobil Phone**

- Don't use mobile phone in hospital, plane, and pay attention to its automatically power on.
- Don't use mobile phone near weak signal and high precision equipment. Lineless electric wave can disturb electric equipment disoperation and other problems. Especially following equipment: Hearing aid, actuator and other medical service, fire detector auto door and other auto control installment. Please enquiry manufactory and local seller.
- Don't strength the liquid crystal screen or use it to him other things, otherwise it will cause liquid crystal board damage and liquid crystal liquid leak. If the liquid crystal liquid into the eyes may cause blind. Please wash your eyes (don't rub it) and go to hospital.
- Don't take apart and modification the phone, otherwise it may cause phone damage, electric leak and electric circuit damage.
- Don't use needle, pen point etc. things to press keypad, otherwise it will damage the phone and wrong operation..
- If the antenna is broken, please use the phone, otherwise it will damage person injury.
- Avoid the phone getting near to magnetism card; phone radiation may clear the information of floppy disk, savings card, credit card.
- Please put pin such little metal thing away the receiver, while receiver working, it has magnetism and can attract these little metal thing, so it will damage person and the phone.
- Avoid the phone getting humid, water and other liquid into the phone; these can cause the phone too hot, electric leak and barrier.

### **Attention Matter of Using Battery**

- Don't throw the battery into fire; it may cause fire and explosion.
- Don't forcefully exert the pressure while inserting battery; otherwise it will cause battery liquid leak, too hot, explosion and fire.
- Don't weld the battery head; otherwise it will cause battery liquid leak, too hot, explosion and fire.
- If the battery liquid into the eyes, it has blind dangerous, don't use your hand to rub your eyes, use water to wash, and go to hospital immediately.
- Don't take apart and modification the battery, otherwise it may cause battery liquid leak,

too hot, explosion and fire.

- Don't use and insert battery near fire or heating utensil, otherwise it will cause battery liquid leak, too hot and fire.
- If the battery temperature up, change color, change shape etc. unusual phenomenon, while using, charging, and saving. Please stop using it and change another one.
- If the battery liquid splash on sink, clothes, this may cause sink burn, wash it by clean water, go to hospital while necessary.
- If the battery leak liquid or smelling, take it from bight fire, to avoid fire and explosion.
- Don't use humid battery; otherwise it may cause battery too hot, smoked and corrosion.
- Don't put the battery in sunlight or near automobile where the temperature is high. Otherwise, it will leak liquid and too hot, reduce its performance, and reduce its use life.
- Don't charge over 24 hours.

### **Attention Matter of Using Charger**

- Please use 200V alternating current, using other voltage may cause electric leak, on fire and damage the mobile phone and charger.
- Prohibit charging short-circuits, otherwise it will cause receives an electric shock, smoked and charger damage.
- Please clean the dust on the power plug in time.
- Don't put container of water beside the charger, otherwise it will cause fire and electric shock.
- If the charger touch water or other liquid, pull the power source from the plug immediately, in case too hot, on fire, electric shock and charger barrier.
- Please don't take apart or modification the charger, otherwise it will cause person injury, electric shock, on fire and charger damage.
- Please don't charge in bath room etc. high humid places, it will cause electric shock, on fire and charger damage.
- Don't touch the charger, line, and plug when your hands are wet, otherwise it will receive an electric shock.
- Don't put heavy things on power line or modification line, otherwise it will cause electric shock and fire.
- Pull out the plug before clean and maintain.
- While pulling the plug hold the charger, pull the power source line will damage the line, cause electric shock and fire.

### **Clean and Maintain**

- Mobile phone, battery and charger have no water-proof function, don't use in bath room, don't rain, eight.
- Use soft cloth to clean the phone, battery and charger.
- Don't use alcohol, diluents or benzene etc. liquid to wipe the phone.
- Dirt plug will cause connect badly, lost electric, and no longer can charge, please clean it in time.

### **General Attention Matter**

#### **Mobile Phone**

- Please use the phone under 5° C~40° C temperature and 35%~ 85% humid environments.
- Please use the phone far away from usual telephone, TV, recorder and office equipment, to avoid effect the affection of these equipment and the phone.

### **Battery**

- Please put the battery in coolly ventilates place, no sunlight.
- Mobile phone's use life is limited, the longer time the shorter life it is, while charge for times and not effective, indicating the end of battery life, you should change an assign new one.
- Don't throw the old battery in normal rubbish, and throw it to assign old battery processing place.

### **Charger**

- Don't charge in following place: sunlight straight, lower 5° C temperature or higher 40° C temperature place, humid/dust place or vibration heavy place, near TV/recorder.

## 2 Before Use

### **2.1 Every part's name and instruction**

#### **2.1.1 Technical parameter**

Outward appearance size	97mm*45mm*12.5mm
Lithium electricity rated capacity	1400mAh
Stand by duration	120~150 hours (according to network)
Call duration	120~150 minutes (according to network)

#### **2.1.2 Keypad instruction**

Left keypad	right keypad
Dial keypad	hand off keypad
Guard keypad	number keypad
* Keypad	# keypad

Left keypad

While stand by, press this keypad can enter main menu and operation.

Right keypad

While stand by, press this keypad can enter phonebook, operate phone record. While editing, it has cancel and backspace function.

Hand off keypad

Press this keypad can end the call or power on (power off), or back to stand by screen.

Dial keypad

Dial or receive call, while stand by, read dialed call record.

Guard keypad

See to 4.1 instructions.

Number keypad

Input number and text, 2-9 can be set as speed dial.

\* Keypad

Input special mark, Chinese punctuation, and mark P and +W.

## # Keypad

Press # keypad can change input method.

### 2.1.3 Side keypad function instruction

1. While stand by, press right upside keypad can enter camera.
2. Right up-down keypad can adjust volume.

### 2.1.4 Remove and install T card

- 1) Remove steps: ① Open T card plug; ②Take out T card.
- 2) Install steps: ①Put the T card into card groove; ②Skid T card plug.

## 2.2 Battery

### 2.2.1 Remove and install battery

Remove steps: ①Push back cover of mobile phone; ②Take the battery from upside.

Install steps: ①Put the upside of the battery down insert; ②Puts the battery down side into bottom.

### 2.2.2 Battery charging

Insert charger into plug

Insert the plug of charger into the right side of the phone

- Power indicated mark flash circularly: if power off, it will appear charging mark on the screen, indicate it is charging. If the power lack badly, it needs some time to indicate charging mark.

When power mark indicates full, and not flash, means finish charge.

If it is power off, screen can also indicate end charge picture, this need several hours. While charging battery, mobile phone and charger will turn hot, this is normal.

After finishing charging, cut off the connection of plug, mobile phone and charger.

Attention:

It must be +5° C~+40° C coolly ventilates place while charging, and must use the supplier afford charger. Use not approve charger may cause dangerous, and violates this phone's approval and repair provision.

When your phone power off automatically or indicate it's lack of power, please charge in time. Manufactory afford mobile phone stand by and call duration is ideal working environment. In fact using, battery's working time will change with network condition, working environment and use method.

- Make sure the battery has been inserted while charging, and can't take out the battery.
- After charging, cut out the connection of charger, mobile phone and power source.
- If you don't cut out the connection of charger, mobile phone and power source, after 5~8 hours, the phone will recharge. We don't suggest this action, because this will effect the function and life of your battery.

## 2.3 Network connection

### 2.3.1 SIM card

You must insert a SIM card in the phone, which is the key to the GSM net.

### 2.3.2 Install and pull out the SIM card

·Be careful to insert and pull out this card; Avoid the scratch and bend of this card, turn off this

phone and take the battery out before installation or pulling out the SIM card.

·Insert the SIM card in the cassette.

**Warning: Make sure the phone is power off before taking out the SIM card. Strictly forbid inserting or taking out SIM card when there is any power cord connected on the phone, or it will harm the SIM card and phone.**

### **2.3.3 Phone On/ Off**

·Press and hold to toggle on/off the mobile service connection

·If the phone is power on before inserting the SIM card, it will show “insert SIM card”. The phone will automatically check whether the SIM card is workable.

### **2.3.4 Unlock SIM card**

To avoid illegal use, SIM card is protected by PIN1. If you had chosen this function, you must input the PIN1 when power on the phone, then the SIM card is unlocked, you could make or receive a call.

Your network supporter will set a standard PIN1 for your SIM card, you should change your personal code as soon as possible.

### **2.3.5 Unlock the phone**

To avoid illegal use of the phone, you can set phone secret code for protection.

·Power on the phone.

·Input the phone lock code, then press “select” to finish unlocking.

**The original code of this phone is 1122.**

### **2.3.6 Connect to net**

When SIM card is unlocked, the phone will search available net.

## **3. Basic operations**

### **3.1 Make a call**

When the sign of the network supporter appears on the screen, you could make or receive a call. On the left above corner, the information stick suggests the intensity of the network signal (it is strongest when there are 4 information sticks).

#### **3.1.1 Make a internal call**

#### **3.1.2 Make a fixed phone call**

#### **3.1.3 Make an international call**

To make an international call, please press “\*” and hold it till the prefix sign “+”of international number, then input the country’s district number and the whole phone number. Delete the number “0” in the city district number.

#### **3.1.4 Make a call from the phone number list**

### **3.2 Emergency call**

### **3.3 Answer a call**

You could choose different ways to answer a call. If you chose **random** in the **answer profile**, you could answer the call by any key; or you need to press the “**dial**” key or **left key** into

“answer”. If the earphone had been plugged in, you could press the button on the earphone to answer the call. If you are inconvenient to press the button, you could choose the “auto” to answer the call (it works only in the earphone profile).

### 3.4 Call history

This phone could store your last call and all the call times since you start using it.

### 3.5 Call menu

**This menu works in the process of call only, and the call waiting, call divert, call barring etc needs network support, please contact the network supporter.**

You could operate these functions in the call menu:

·Pause

·End

·New call

·Phonebook

·Message

·Record

·Mute/Reinstate

·Diaphones

·Multi-communicate

## 4. Function menu

1. Phonebook	1. Quick search		
	2. Search entry		
	3. Add new entry		
	4. Copy all		
	5. Delete		
	6. Caller group		
	7. Extra number		1. Owner number
			2. Service dial number
			3. Emergency number
	8. Settings		1.Memory status
		2.Preferred status	

		3.Fields
		4.My vCard
	9.Caller picture	
	10.Caller ring tone	
	11. Caller video	
2. Messages	1.SMS	
	2. MMS	
	3. Voice mail server	
	4. Broadcast message	
3.Call history	1. Missed call	
	2. Dialed call	
	3. Received call	
	4. Delete call record	
	5. Call times	
	6. Call cost	
	7. SMS counter	
	8. GPRS counter	
4. Tools	1. Calendar	
	2. To do list	
	3. Alarm	
5. Fun & Games	1.Classic games	1.Mahjong
		2.Puzzle
		3.Magicsushi
	2. Themes	
	3. Stopwatch	
6. Network service	1. STK	
	2. WAP browser	
	3. Data account	
7. Multi-media	1.Image viewer	
	2.Sound recorder	
8. Extra	1.Calculator	
	2.Unit converter	
	3.Currency converter	
	4.Health	
	5.E-book reader	
	6.Bluetooth	
9. Settings	1.Pen calibration	
	2.Phone setup	1. Time and date
		2. Schedule power on/off
		3. Language
		4. Preferred input method
		5. Display characteristic
		6. Greeting text

		7. Speed dial
		8. Dedicated key
		9. Auto update date and time
		10. Flight mode
		11. Handwriting
		12. Misc setting
	3. Call setup	1. Caller ID
		2. Call waiting
		3. Call divert
		4. Call barring
		5. Line switching
		6. Call time reminder
		7. Call time display
		8. Auto redial
		9. Close user group
		10. IP number
	4. Network setup	1. Network selection
		2. Preferred network
		3. GPRS connection
	5. Security setup	1. SIM lock
		2. Phone lock
3. Auto keypad lock		
4. Fixed dial		
5. Barred dial		
6. Change password		
6. Restore factory settings		
7. Sound effect		
10. User profiles	1. General	
	2. Meeting	
	3. Outdoor	
	4. Indoor	
	5. Headset	
	6. Bluetooth	
11. Shortcuts		
12. File manager		
13. Analog TV		
14. FM radio		
15. Audio player		
16. Video player		
17. Video recorder		
18. Camera		

#### 4.1 Phonebook

You can store the name card's information by phone book in the phone. Such content can be

stored: name, phone number, family phone number, company name, email address, company

phone number, fax number, birthday, photo, melody choosing, incoming call group information

This phone can store 300 phone numbers; the SIM card's storage is different because of its different capacity.

## **4.2 Messages**

You can send and receive English and multimedia messages.

### **4.2.1 SMS**

#### **4.2.1.1 Inbox**

You can read the received messages in the submenu "inbox" and operate it according to the options.

#### **4.2.1.2 Outbox**

You can read the sent messages in this submenu and operate it.

#### **4.2.1.3 Write a SMS**

Please make sure you had set a SMS service number before write a message.

**Some SMS center doesn't support the long SMS which has more than 160 English letters in some cities and areas.**

#### **4.2.1.4 Common note**

You could input some common sentences in the "**common note**" to avoid repeating input the same words.

#### **4.2.1.5 Settings**

You need to do some necessary settings before use SMS function.

##### **·SMS setup**

Profile setup

Status setup

Capacity checking

SMS sending setup

##### **·SMS service center number Setup**

Please contact your network supporter to get the SMS service center number.

##### **·Status report**

You could check whether the SMS is received by the receiver if you set this function "open".

**This function needs network support.**

## **4.3 MMS**

- It can send and receive messages including pictures, Voice of multimedia and so on.
- In addition to the transmission between mobile transmission, but also transmission between in mobile phones and electronic mail.

## **4.4 Voice Box**

The voice message is stored on network, so if you want to hear the voice message,

you will have to dial the voice box number.

#### **4.5 Call record**

##### **4.5.1 Missed Call**

- That function allows the row form that you can look into recently missed 100 telephone numbers , use the “Missed Calls” function, can check the date and time of every call.

The functions as follows:

- Dialing: dial this number
- Delete: delete the record.
- Save: save this number to phone book
- Send message: send message to this number.

##### **4.5.2 Dialed Phone:**

- That function allows the row form that you can look into recently 100 telephone numbers , including have already connected or try to dial’s telephone number, use "dialed calls" function, can look into date and time.

Related functions as follows:

- Dialing: dial this number
- Delete: delete the record.
- Save: save this number to phone book
- Send message: send message to this number.

##### **4.5.3 Received Call**

- That function allows the row form that you can look into recently received 100 telephone numbers , use the “Received Calls” function, can check the date and time of every call.

The functions as follows:

- Dialing: dial this number
- Delete: delete the record.
- Save: save this number to phone book
- Send message: send message to this number.

##### **4.5.4 Delete Call logs**

Can choose Clear dialed calls, received calls and missed calls.

1. Delete all dialed calls
2. Delete all received calls
3. Delete all missed calls
4. Delete all record

##### **4.5.5 Call Time**

Use this functions to look into all phone time and last call times ( in the form of hour, minute and second to display)

Note: the actually phone time and service rate from the documents of the supplier is different from it. The function is subject to network and the duty.

- The last call time: display the time of the last call
- All call time: display all time of call in and call out
- Reset : the time calculator reset

#### **4.5.6 Call rate**

- You can use this function to look into your all rate and last call rate.

Note: the actually phone time and service rate from the documents of the supplier is different from it. The function is subject to network, please consultant to the local network operator for other functions.

1. The last call rate: display the rate of last call
2. All calls rate: display all call rate
3. The maximum rate: display the maximum rate.

#### **4.5.7 Message rate**

1. Sent: display the rate of sent message.
2. Received: display the rate of receive message.

You can click the left soft button to delete these two records.

#### **4.5.8 GPRS rate**

1. The last sent rate: display the rate of last sent.
2. The last receive rate: display the rate of last received.
3. Sent rate in totally: display the rate of totally sent
4. Received rate in totally: display the rate of totally received.

#### **4.6 Calendar**

You can check the date and set calendar here.

##### **4.6.1 Memorandum**

You can store 10 memorandums here.

##### **4.6.2 Alarm**

This mobile phone can set 3 alarms.

##### **4.6.3 World time**

You can shift the time from this city to another in this function.

##### **4.6.4 City search**

When you receive a call, it will display the city of the number.

##### **4.6.5 Electronic reader**

This function can help to read the “.txt” file, after you put this kind of file under the EBook folder, you can read it.

#### **4.7 Games**

#### **4.8 Service**

##### **4.8.1 STM card**

This function is afforded by network supplier, if SIM card and network can't support this service, this function can't be used. Award more information please connect with network support.

##### **4.8.2 Brower**

Your mobile phone support WAP service, you can enquiry your network shipper. This service function can make you award relative news, weather report and air scheduled flight etc. information.

##### **Attention:**

GPRS service need network to support, must opened and in GPRS network cover district, only in this situation can use GPRS service.

- Brows homepage: Log in homepage. Homepage is the assign website in which you

open link setting. If you haven't set it, you will use manufactory preset website.

-Bookmark information: Indicate already book marks; choose the website which can connect to this bookmark directly.

-Input web address: Choosing this option can input any WAP or other internet website.

-Website history record: Record all the web address you logged before.

-Brower setting: setting of browsing web.

1. Edit
2. Clear history of web sites
3. Clear cache
4. Download picture setting
5. Service inbox setting

-Service inbox

-Online function instruction:

1. Forward
2. Back
3. Homepage setting
4. Add as book marks
5. Visit homepage
6. Input website
7. Book mark information
8. Exit

#### **4.8.3 Account information**

-GSM data:

**Choose one account to enter:**

1. Name
2. Number
3. User account
4. Password
5. Line patterns
6. Speed
7. Net Domain

- GPRS:

Choose one account to enter.

1. Name
2. Number
3. User account
4. Password
5. Certification Mode

#### **4.9 Milt-Media**

This function contacts albums and records

#### **4.10 Additional features**

You can use the Calculator, Unit conversion, exchange rate conversion, health management Bluetooth

## 4.11 Setting

### 4.11.1 Touch screen calibration

### 4.11.2 Phone setting

In this function, you can set the phone display and function setting, such as Date and time, Timing shutdown, Language, Default input, Default code, Standby menu display, handwrite setting, flying setting, etc.

### 4.11.3 Call setting

- **Number for this phone:** can set if the people calling can see your number or not.
- **Call waiting**
- **Call divert**

- When you set up a call transfer feature, as long as some one call you, Calls will be automatically transferred to your pre-set fixed telephone, mobile phone, voice mail, in order to avoid lose the call information.

Classified into voice, data, and fax three models, the ways to divert are:

1. **Divert all voice calls:** the corresponding option is cancel,(can cancel the setting for unconditional divert). To voice mail, (Unconditional transferred to the voice mail) to telephone number (Unconditional transferred to telephone number).service state inquiry.
2. **A conditional divert:** include divert if busy, divert if no answer, and divert if unreachable three types. The related options are: cancel (can cancel the setting), to voice mail (transfer to voice mail), to telephone number (transfer phone number), service state inquiry.
3. **Cancel all divert:** cancel above of all call divert.

- **Call barring:** This function used to restrict the make and receive voice, data, fax message. To use this function, you need to obtain the password from the service provider.

1. Forbidden to call out
2. Forbidden to call in
3. Cancel the restrict
4. Change the password

- **Call shift:** Shift between 1 and 2 line.
- **Time of call:** Choose whether display the time of call
- **Sound of call**
- **Dial back automatically**
- **Close the group**

### 4.11.4 Security setting

**SIM Lock:** Prevent the illegal use of the user SIM card. If you active this function.

If input error three consecutive times, SIM card will locked automatically and show us the PIN code had been locked.

**Phone Lock:** Prevent the illegal use of the phone. You will be asked to input the password every time you boot the phone. The default password is 1122; please change it as soon as possible.

**Keyboard Lock:** If you set this function, you will need to input the password after a

period (you can set this period) of not using the phone. When you need to use the phone, press the right soft button, then press #. This function will need a SIM card inserted.

**Secret record** When visit the private information, for example, phone book, message, call record, photo book, MP3 player, electronic file, T card information, ect. You will need to input the password. If you want this function, you have to set it, and input the password 1122.

**Long distant control** Through this function, you can control another mobile phone by sending a fixed format order

Function	Commands
Shut down at once	RMCTRL88+Control characters +shut down
Shut down automatically every time boot for 3 minute	RMCTRL88+ Control characters+ Repeated shutdown
Delete phone book(include the phone book from SIM card and mobile phone)	RMCTRL88+ Control characters+ delete phone book
Delete all the calling record	RMCTRL88+ Control characters +delete calling record
Delete all the message	RMCTRL88+ Control characters +delete message
Format all the card (include the NVRAM in the phone and T-Flash)	RMCTRL88+ Control+ format store
Send the phone book to the controlled photo through message. If you change SIM card, you can also send the photo book on the SIM card too.	RMCTRL88+ Control +retrieve phone book

When you use this function, you should set the Control characters (normally 4 digits). When setting, you will have to input the password. For example, you set the Control character is 1234, and you want the controlled phone shut down, you should send a message “RMCTRL881234shutdown” to the controlled phone. Note: The RMCRL should be capital.

Suggest: Before you use this function, you should active the Tracking Security function. If you phone is lost accidentally, you can control the phone before your SIM card is change.

### **Tracking Security**

You must set up a phone number for notification before you use this function. When the phone turn on which you tracing, the system will send message to the set phone automatically. To tell you which phone number using this tracing phone.

Open this function need your phone password, the tracing phone will bind with your SIM, if your open this function.

As long as you change SIM, it will send message to the phone number you had set. (Just your phone turn on, it will send one time), since you can know your phone was

used by which number at any time.

#### Fixed Dial

If your SIM support with this function, you can dial, you can set only dial the selected telephone numbers.

Barred dial: you can set up barred dial some phone numbers.

Change Password: include PIN, PIN2 and the phone password.

Notice: some functions need the support of your network supplier.

#### **4.11.6 Restore factory setting**

The initial Password of Restore factory setting is: 1122

#### **4.11.7 Sound effect**

This function can be configured Equalizer

### **4.12 Profiles**

This phone has six profiles to chose. For example, general, meeting, outdoor, indoor, headset and Bluetooth. You could set these functions before you want to use it.

#### **4.12.1 General**

You can choose open or set personal information in here.

Open: choose activate enter to the general environment.

Personal Setting:

You can set follow functions: tone set up, volume, alert type, ring type, extra tone, and answer mode.

#### **4.12.2 Meeting**

The operation is same as the General.

#### **4.12.3 Outdoor**

The operation is same as the General.

#### **4.12.4 Indoor**

The operation is same as the General.

#### **4.12.5 Headset**

This function opens automatically when you insert the headset.

#### **4.12.6 Bluetooth**

This function opens automatically if the phone connects with Bluetooth.

### **4.13 Shortcut Function**

You can set up shortcut way in here.

This phone provides eleven shortcuts, open the menu to choose shortcuts to set this function.

The way for setting as follows: choose a shortcut way in the main interface of shortcut setting. Push left soft button to edit, then select left soft key to make sure after you choosing a menu. Then the setting of shortcut is completed.

### **4.14 File Manager**

For save the user files, you can open old folder, establish new folder or format all files when you enter the options.

### **4.15 Phone TV**

The phone have Watching TV function, choose Phone TV enter the screen.

There have four options provide to you: Choose the District, Channel List,

Automatically Search, Mode Selection...

#### **4.16. FM Radio**

Choose FM Radio can enter Radio Interface, push left soft key to choose, you can choose channel list(can edit at least 20 channel), input manually, search automatically and setting, the last is setting.

#### **4.17 Audio player**

Choose Audio Player and enter MP3 screen.

The up, down, left and right key can stop /play /pauses/choose the last one or choose the next one to play.

Enter left soft key enter play list, search song by the scroll then play it.

#### **4.18 film player**

Choose the menu of film player, you can look the film which you had storage on the film list, please click 'options' to play, send, rename, delete, delete all files. Push '\*' enter full-screen playing, also push '\*' withdraw full-screen playing.

#### **4.19 Film Recorder**

Your phone provides animation record function. Push 'ok' button for record after you enter film recorder. You can to the player play this record, and set the size of the record, if you don't want this record finally, you can restore default.

#### **4.20 Camera**

This phone can take photos, you can take photos whenever, wherever, just push 'ok' button to use it.

The following is some functions of the camera:

Album

Camera Setting

Image Setting

White Balance

Effect Setting

Add Frame

Storage Path

Restore Default

## **5. Input Methods**

The phone provide input methods have: English, Smart English, Digital input, English Handwriting, and stroke input. It also support Simplified Chinese Input Method, You can push '#' button to change different input ways.

-- End --